





# OPERATING INSTRUCTIONS

Cheetah Stealth ACd06 & ACd07




## STEP 1

Slide inside label holder disk onto label holder shaft.  
Be sure to slide it all the way until it




## STEP 2

Slide label roll onto label holder shaft.




## STEP 3

Place label roll onto inside label roll holder and then slide the outside label holder disk into place.




## STEP 4

Slide the label roll retaining collar into place and tighten thumb screw to keep the label roll in place.




## STEP 5

Thread label stock under tension shaft and then between the pressure sheet and peel bar.




## STEP 6

Remove label liner take up fork and wrap label liner around the peel bar and then around the top of the label liner take up shaft.




## STEP 7

Re-attach liner take up fork over liner



## STEP 8

Turn on label dispenser. Up is on and down is off. Always turn off when changing label rolls or when not in use. First label will advance and stop when it trips the photo eye.



## STEP 9

Dial-A-Size label length adjustment. Push in the spring and turn the disk Clockwise or counter clockwise to the Appropriate advance position.

**Cheetah Systems LLC**

204 37th Avenue North #129 / St. Petersburg, FL 33704 / 727 642 1668

[www.cheetahsystemsllc.com](http://www.cheetahsystemsllc.com)